




ECONOMY projection screen
MANUAL



For wall suspension
Use the key hole slot at the back of the hanging bracket for wall suspension.
Position screws or other fasteners into the wall and hang the screen by using the slots.

For ceiling suspension
Use the D-shaped bracket.
Position two screw hooks in any solid surface.


To lower the projected image
Pull the screen down all the way.
HESITATE-then allow the screen to retract
VERY SLOWLY until it locks into place.

To raise the projected image
Pull down the pull cord,quickly as a window shade.
Keep control of the image surface.Do not allow it to roll uncontrolled into the case to prevent damage.

CAUTION
Over speed is likely to appear when the screen rolls back into the case,thus causing the handle to hit the frame.Pull with care to prevent damage to parts of the product.

Legamaster International B.V.
Lochem – The Netherlands
www.legamaster.com



<div>备注</div> <div>技术要求： 1、白底黑字，A4 80g书写纸单面印刷。 2、印刷内容正确；清晰无重影； 表面清洁无脏污，等现象。 3、符合ROHS要求。</div>							材质/MATERIAL： A4 80g书写纸			
							系列/MODEL NAME：		型号/MODEL NO：	
							EDDING		标准手拉幕	
							部品名/PART NAME：		部品号/PART NO：	
							说明书		3005000138000	
△	TEN NO.		日期		设变					
初版	TEN NO.	TEN1103058	日期	11.03.21	比例	1：1				
批准		审核	设计		页次	1/1				
吴志勇		邹景旺	刘芳		单位	MM				
<div> 东莞澳星视听器材有限公司</div>										